



# Vehicle Measurement Interface

Ver. 07. 06. 2006





# Introduction to VMI



Module: A-07-001 (p.01)

"VMI" (Vehicle Measurement Interface) is a Module for performing measurements (DVOM, Oscilloscope, etc.).

DVOM (Digital Volt Ohm Meter) uses oscilloscope probes to measure Voltage, Resistance, frequency, Duty(+), Duty(-), Pulse(+), Pulse(-)", and shows current output data with MAX(+PEAK), MIN(-PEAK), AVG(AVERAGE) at the same time.

Oscilloscope function has two channel modes when taking measurements, which are 2CH(CH-A, CH-B)mode and 4CH(CH-A1, CH-A2, CH-B1, CH-B2)mode.

Simulation function supports "Actuator driving test" and "Simulation test".

To activate DVOM, Oscilloscope, Simulation functions, VMI must be turned "ON" using supplied battery extension cable.





Safety Warnings and Cautions before Use



Module: A-07-002 (p.01)

This section contains WARNINGS and CAUTIONS for safe usage of GDS. Before use, the user should read the following information.



This indicates items for which incorrect handling may result in a major accident involving death or serious injury.

- The VMI should be secured in a safe location when operating the vehicle to avoid interference with other vehicle equipment.
- When connecting VMI module with a DC adapter, do not use the adapters other than specified DC adapter (7~35VDC).
- Ensure all cables are properly connected during operation. Do not disconnect USB cable or power cable unless finished with the equipment.
- Ensure that the module is installed in a safe and secure location to avoid interference with other vehicle equipment.
- Do not disassemble the VMI module.
- Do not measure 110V or 220V alternating voltages with VMI module.
- Do not measure data using AC/DC adapter on oscilloscope 2 or 4 channel mode.





WEEE (Waste Electrical and Electronic Equipment) symbol shown in [Figure 1] is indicated on the back of the VCI main module, VMI main module, and Trigger module.

Please follow the regulation guide for disposal of Waste Electrical and Electronic Equipment. Use caution disposing of the Trigger module; it contains a lithium battery. Users must follow the regulations when replacing or discarding this battery.



Disposal of Old Electrical & Electronic Equipment (Applicable in the European Union and other European countries with separate collection systems)

This symbol on the product or on its packaging indicates that this product shall not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. The recycling of materials will help to conserve natural resources. For more detailed information about recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.



# Components of VMI Kit



Module: A-07-004 (p.01)

# VMI Hardware Components

Part name	Part number	Description	Qty.
AssyVMI module	GHDM - 310000	VMI module for DVOM, Oscilloscope and simulation test.	1
Cable - VMI Power	GHDM-340000	Supplies DC power to VMI from the vehicles battery terminals directly. Length 6m.	1
Cable-Mini USB	GHDM-360000	Cable for communication between VMI and Information Terminal. Length 3.5m.	1

Part name	Part number	Description	Qty.
Scope Cable (CH-A) - Red	GHDM-321000	Scope Cable (CH-A) - Red is used for Oscilloscope and Actuation functions and supports both Differential and Single ended. The connector end has 2keys and the probe is colored in red. Length 1.5m.	1
Scope Cable (CH-B) - Yellow	GHDM - 322000	Scope Cable (CH-B) - Yellow is used for DVOM and Simulation test functions and supports both differential and Single ended. The connector end has 2keys and the probe is colored in yellow. Length 1.5m.	1
Scope Pin - Red	GHDM-351000	When measuring data with back probe, use these in front of supplied Scope cables. These are colored in red.	2
Scope Pin - Black	GHDM-352000	When measuring data with back probe, use these in front of supplied Scope cables. These are colored in black.	2

Part name	Part number	Description	Qty.
Scope Clip - Red	GHDM-353000	When measuring data at the specific area, use these in front of supplied Scope cables. These are colored in red.	2
Scope Clip - Black	GHDM-354000	When measuring data at the specific area, use these in front of supplied Scope cables. These colored in black.	2
Spring Pin	GHDM-355000	When measuring data with back probe, use these in front of supplied Scope cables.	2



# **Specifications and Features**



Module: A-07-005 (p.01)

# **VMI Specifications**

**General Features** 

lte	m	Specifications	
Micro Controller		ARM9 (S3C2410A) @ 208MHz	
Memory		RAM 32MByte	
		ROM 32MByte	
Operating Vol	tage	7~35V DC	
Temperature	Operating	0℃~50℃ (32°F~122°F)	
	Storage	-20°C ~ 80°C (-4°F ~ 176°F)	
Relative	Operating	Noncondensing @ 0 ℃ ~ 10 ℃ (32°F ~ 50°F)	
Humidity		95%RH @ 10℃ ~ 30℃ (50°F ~ 86°F)	
		70%RH @ 30℃ ~ 50℃ (86°F ~ 122°F)	
	Storage	Noncondensing @ -20℃ ~ 80℃ (-4°F ~ 176°F)	
Operating Mo	de	Oscilloscope, DVOM, Simulation Test	
Power Consu	mption	Typical 5W @12V(Oscilloscope, 20V Range)	
Dimension		235mm × 109mm × 60 mm (9.25inch × 4.29inch × 2.36 inch)	
Weight		0.73 kg (1.61 lbs)	

# PC Interface

ltem	Specifications
Wire protocol	USB 1.1

# Oscilloscope Features

lt	em	Specifications		
Voltage Range	2CH	±400 mV, ±800 mV, ±2V, ±4V, ±8V, ±20V, ±40V, ±80V, ±200V,		
		±400V		
	4CH	±4V, ±8V, ±20V, ±40V, ±80V, ±200V, ±400V		
Vertical Resolution		10 Bit		
Measurable	±400 mV ~ ±2V	±20V <sup>1)</sup>		
Differential DC	±4V ~ ±80V	±200V		
Voltage Range	±200V ~ ±400V	±400V		
Sampling Modes	3	Normal mode / Peak mode		
AC/DC Coupling	]	Supported		
Input Impedance	e	2 $M\Omega$ respect to power ground		
	2CH	100 $\mu$ s, 200 $\mu$ s, 500 $\mu$ s, 1 ms, 2 ms, 5ms, 10 ms, 20 ms, 50 ms,		
Time Pange		100 ms, 200 ms, 500 ms, 1s, 2s, 5s		
Time Range	4CH	200 $\mu$ s, 400 $\mu$ s, 1 ms, 2 ms, 4ms, 10 ms, 20 ms, 40 ms, 100 ms,		
		200 ms, 400 ms, 1s, 2s, 4s		
Sampling	2CH	Max. 500k sps per channel simultaneously (Peak mode)		
Speed	4CH	Max. 250k sps per channel simultaneously (Peak mode)		

1) Using 2CH Differential Mode, in case of measuring voltage is set in over the 20V, the VMI cannot recognize under 400 mV(800 mV or 2V) even if the chosen voltage range is in  $\pm$ 400 mV(800 mV or 2V), In this case, the user must change the voltage range to measurable range.

# **DVOM** Features

ltem	Specifications
DC Voltage Range	$\pm$ 400 mV, $\pm$ 4V, $\pm$ 40V, $\pm$ 400V
AC Voltage Range	Not Supported. DO NOT Measure AC Outlet (110V or 220V)
Resistance Range	400Ω, 4 kΩ, 40 kΩ, 400 kΩ, 10 MΩ
Frequency Range	1 Hz ~ 10 kHz (Threshold Level: 2.5±0.5V)
	0.1% ~ 99.9% @ 1 Hz ~ 100 Hz
	1.0% ~ 99.0% @ 100 Hz ~ 1 kHz
Duty Range	3.0% ~ 97.0% @ 1 kHz ~ 3 kHz
	5.0% ~ 95.0% @ 3 kHz ~ 5 kHz
	10.0% ~ 90.0% @ 5 kHz ~ 10 kHz
Pulse Width Range	<b>10</b> μs ~ <b>1000ms</b>

# Simulation Test Features

	ltem	Specifications
Voltage	Output Range	0.0V ~ 5.0V
Output	Forced Stop	When output data is out of output range (0.0V~5.0V).
Frequency	Output Range	1 Hz ~ 999 Hz
Output	Duty	50%
	Voltage Level	High: 5V, Low: 0V
	Forced Stop	When output data is out of voltage range between
		(-)1.0V and 6.0V respect to power ground.
Duty Output	Frequency Range	1 Hz ~ 999 Hz
	Duty Range	1% ~ 99% @ 1 Hz ~ 99 Hz (1% or 10% per step)
		10% ~ 90% @ 100 Hz ~ 999 Hz (Only 10% per step)
	Pulse Width	Depends on frequency or duty
	Allowable Current	Max. 2A±0.3A

# FCC/CE Notification

Contains FCC ID: NI3-IS20V35

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.



# Main Components



Figure 1. Component Identification (RIGHT)



Figure 2. Component Identification (LEFT)



• VMI uses only USB port as its medium and does not support W/LAN protocol.

Installation of Power Cable

To turn on the VMI module, first connect the power cable from the battery to the VMI and press the main power switch. VMI uses vehicle's battery for its power source.

Connect red and black cables to positive(+) and negative(-) terminals of the vehicle battery respectively.



#### Figure 1. Connecting the Cable-VMI Power

# **User's Manual**

The Rubber Shroud is designed to hold the fitted battery power extension cable, to minimize the interference with other cables. Battery clamps are insulated to prevent short between (+), (-) ends. Clamp handles are designed with probe inserting holes for the users convenience.

With the VMI connected to the battery properly, pressing the POWER button located in the middle of the VMI to turn on the VMI. To turn off the VMI press the POWER button for more than 3 seconds, the VMI power will be turned off.

## **VMI Display Operation**

The VMI equipment has an LED display for checking VMI operating conditions.



Figure 1. LED status on VMI Module

# POWER

LED is turned on RED when VMI is in normal operating mode.

# PC COMM

Connecting condition between PC and VMI is confirmed based on LED blinking.

During VMI firmware update, Power and PC COMM LED is turned on ORANGE.

![](_page_15_Picture_2.jpeg)

- Using other cables or adapter rather than provided cable-VMI power and adapter can cause fatal damage to the VMI.
- Do not reverse the polarity when connecting the VMI module to vehicle battery.

## Installation of Cable - mini USB

VMI must be connected with USB cable, and this means that it is not support wireless LAN between Information Terminal and VMI module.

While installing the USB cable to the VMI module, the USB cable must be tightly connected in order to avoid communication loss.

When removing the USB cable, press the connector lock tab first, and then disconnect the cable.

![](_page_15_Figure_9.jpeg)

Figure 2. Connecting the Cable-Mini USB to the VMI module

There are no lock tabs at the Information Terminal side connector on the USB cable, therefore use caution when checking the connecting condition between the USB cable and Information Terminal.

#### Installation of Scope Cables

VMI can be fitted with CH-A, CH-B and AUX scope cables and their applications are as below.

CH-A : Supports 2 Channel with CH-A and 4 Channel with CH-A1 and CH-A2 in Oscilloscope Function. And also supports (+) and (-) in Duty Output function during the Simulation Test.

CH-B : Supports 2 Channel with CH-B and 4 Channel with CH-B1, CH-B2 in Oscilloscope Function. And also supports DVOM function and Voltage/Frequency output during the Simulation Test.

AUX : Used for connecting cables for exclusive channel.

![](_page_16_Figure_7.jpeg)

Figure 3. Connecting the Cables

![](_page_16_Picture_9.jpeg)

- Use only provided scope cable, scope pin, scope clip and spring pin to take measurements, and they must to be installed in appropriate place.
- Do not use any accessories except ones that are provided from GIT and all products must be used in allowed area. If it is not, VMI can be damaged seriously.
- Do not use adapters other than provided DC adapter from GIT.

# **User's Manual**

![](_page_17_Picture_2.jpeg)

The Scope Cables (2 keys) & the AUX Probe (1 key) are keyed differently to prevent them from being inserted in the wrong position on the VMI module and scope cable for the users. Refer to [Figure 4].

Figure 4. 2 Key Structure and Application

When unplugging the scope cables, be sure to unlock the push-pull connector shell(Refer to [figure 5]) by sliding insert end before pulling the cable out.

![](_page_17_Figure_6.jpeg)

Figure 5. Removing the Scope Cable

# Probe Hanger and Hood Buckle Instruction

Probe hanger and hood buckle have been designed for the users convenience during usage of VMI in the workstation.

![](_page_18_Picture_4.jpeg)

Figure 6. Using Hood Buckle Instruction

![](_page_18_Picture_6.jpeg)

Figure 7. Probe Hanger Instruction

![](_page_19_Picture_2.jpeg)

- Do not place or hang VMI module near incandescent light.
- Check the location of keys and insert when connecting scope cables.
- When removing the cable-mini USB, press the lock tab first at VMI module side and then pull the cable-mini USB connector.
- When removing scope cables, be sure to unlock the tab by sliding insert end before pulling the cable out. Refer to [Figure 5] at "Cable connection method and Applications".
- When hooking up cables like USB, DC power supply and scope cables, be sure to secure the cables so that cables do not interfere with other actuators (cooling fan, fan belt, etc).

![](_page_20_Picture_1.jpeg)

# VMI Firmware Update

![](_page_20_Picture_3.jpeg)

Module: A-07-007 (p.01)

## Check Version and VMI Firmware Update

VMI Firmware version can be reviewed at Configuration of GDS and uses same update method as VCI.

#### **VMI Firmware**

"VMI Firmware" item represents the version of the "Firmware" in the VMI module.

#### **VMI Update**

It is a function for downloading the latest VMI Module "Firmware". It establishes settings for the communication between the PC and VMI through a USB cable, and downloads the latest "Firmware" from the PC to the VMI module when the user presses the "Firmware Update" button.

GDS ++ - Micros	soft Internet Expl	orer					
GLOBAL DIAGNOSTIC SYSTEM			Notic	ce 🛛   Configuration	Search	LOG OFF	
Configuration	ı						
Vers	ion	Dealer	Server Connection	Units of Measure	Self Test (\$	Semi-Test)	
• Version					to (Sotting (	Cuido	
Software	E-H-1-0-1.01			vci,viii opua	te / Setting (	Sulue	
Contents	E-H-1-0-1.00						
VCI Firmware	FW:1.26 DLL:	1.26	Firmware Update		50	0	2
VMI Firmware	FW:1022 OCX	: 1031	Firmware Update			0	
VCI Wireless	Setting			VCI			
1	2	3 4	5	Onnect the VCI DLC ( Turn On the VCI	or Cigar Powe	r to the vehic	le.
с	C	C	c c	Onnect the USB cable	e from VCI to t	he PC.	
6	7	8 9	10	<ul> <li>Update/Save VCI Settir</li> <li>VMI</li> </ul>	ng.		
С	С	C	<u> </u>	Connect the VMI to batt	tery (+) and (-)	) terminals wi	th
11	12	13	15	power cable properly.			
c	C	c	с <u>с</u>	Connect the USB cable	e from VMI to t	he PC.	
	Read VCI Sett	ing Save VCI Se	tting	<ul> <li>Update VMI.</li> </ul>			
							_
	7 - T						
Shop Manual TSB	Case Analysis ETM	DTC Guide DTC	Current Actuation Flight Test Data D	VOM Oscilloscope Simulation LE	CU Fault Code grade Searching	e Knowledge Ir Feedback U	nterr Jpda

Figure 1. Configuration – VMI Firmware Update

# **User's Manual**

![](_page_21_Picture_1.jpeg)

Only Channel B is used when the DVOM Mode is selected. Measurements of Voltages, Resistance, Frequency, DUTY(+), DUTY(-), Pulse(+) and Pulse(-) can be configured to display current data with MAX(maximum), AVG(average) and MIN(minimum) at the same time.

BLACK probe applies to Minus (–) probe and RED probe applies to Plus (+) probe. DVOM display range is set to Auto Range.

During vehicle communication, this pop-up window will enable MULTIMETER function. This window can be dragged and closed.

This function cannot be used during Oscilloscope and Simulation tests.

![](_page_21_Picture_6.jpeg)

Figure 1. Pop-up Screen of DVOM Function

#### Voltage

Voltage measurements can be made using CH-B and output is shown in (MAX)/(MIN)/(AVG). Use Minus (–) probe and Plus (+) probe to find differential voltage between the two.

"Reset" will reset all voltage values (MAX)/(MIN) and (AVG) to Zero. Then display the new current data received by the VMI.

Zero Set is not supported in Voltmeter mode.

![](_page_22_Picture_6.jpeg)

Figure 2. Measuring Voltage

![](_page_22_Picture_8.jpeg)

- MULTIMETER measures DC VOLTAGES ONLY.
- Only measure Resistance with the **Power OFF** to that circuit.

# Resistance

Resistance can be measured using CH-B. It displays in (MAX)/(MIN)/(AVG). This function can be used when measuring resistance between the two probes.

"Reset" will reset all values (MAX)/(MIN) and (AVG) to Zero. Then display the new current data received by the VMI.

"Zero Set" is used to calibrate the meter reading to a Zero (0) Ohm's before making a resistance measurement.

"0L" indicates, "Overload" and shows Out of Range status.

![](_page_23_Picture_2.jpeg)

Figure 3. Measuring Resistance

To get an accurate measurement always zero the meter before making any measurements. Just press the Zero Set button while shorting the positive (+) and negative (-) probes together.

![](_page_23_Picture_5.jpeg)

Figure 4. Zero Set Function

Zeroset
How to use 'Zero Set' Function
This function is for calibrating resistance offset
DATA CHECKING
3. Select 'GO' button.
Go Cancel

Figure 5. Zero Set Function

## **User's Manual**

When zero set has succeeded, following pop-up will show. Press OK and continue measuring resistance.

![](_page_24_Picture_3.jpeg)

Figure 6. Zero Set Succeed

![](_page_24_Picture_5.jpeg)

- Resistance measurements are affected with temperature and scope cable connection, therefore user should always zero the meter first before measuring resistance.
- Internal VMI circuit can be damaged when inflow of more than 5V through scope cable is continued over 1HR in RESISTANCE MODE.

# Frequency

Frequency can also be measured using CH-B. Frequency is displayed as Hertz or the number of cycles that have occurred during a 1-second period of time. If the display shows 182.2Hz, this implies that 182.2 cycles have taken place during a 1-second period of time.

"Reset" will reset all values (MAX)/(MIN) and (AVG) to Zero. Then display the new current data received by the VMI.

Resets AVG (average) value back to the basis of current data by pressing the reset button.

Zero Set is not supported in the Frequency mode.

"0L" indicates, "Overload" and shows Out of Range status.

![](_page_24_Picture_14.jpeg)

Figure 7. Measuring frequency

#### Duty

Duty cycle can be measured with CH-B and this will display (+) Duty and (-) Duty as a percentage from 0% to 100%.

Click Duty once to activate and click Duty (-) again to change (-) negative values to (+) positive values. "Reset" will reset all values (MAX)/(MIN) and (AVG) to Zero. Then display the new current data received by the VMI.

Zero Set is not supported in the Duty cycle mode.

![](_page_25_Figure_6.jpeg)

Figure 8. Measuring (-) Duty

Multim	eter ( <mark>c</mark> i	hannel				
Volt	Ω	Hz	Duty(+) W	lse idth(-)	Reset Zero	) S
				MAX	23.50	*
6	-	5	%	AVG	23.50	*
				MIN	2350	

Figure 9. Measuring (+) Duty

#### \* TIPS

(+) DUTY : This implies the percentage rate of pulse ABOVE the basis of threshold voltage.

(-) DUTY : This implies the percentage rate of pulse BELOW the basis of threshold voltage.

This will display the on/off duty cycle time of the component being tested.

![](_page_25_Figure_14.jpeg)

![](_page_25_Figure_15.jpeg)

## Pulse Width

This function uses CH-B and measures PULSE WIDTH as a function of time in seconds.

Click Pulse Width once to activate and click Pulse (-) again to change (-) negative pulse width values to read (+) positive pulse width or (-) minus pulse width values.

"Reset" will reset all values (MAX)/(MIN) and (AVG) to Zero. Then display the new current data received by the VMI.

Zero Set is not supported in the Pulse Width mode.

![](_page_26_Figure_7.jpeg)

Figure 11. Measuring (-) Pulse Width

Volt	Ω	Hz	Duty		រ្មីth(+)	Reset Zei	ro Se
	-			-	MAX	1.710	ms
	7		Π	ms	AVG	1.705	ms
					MIN	1700	ms

Figure 12. Measuring (+) Pulse Width

#### \* TIPS

(+)Pulse Width : This implies the duration of pulse ABOVE the basis of threshold voltage.

(-)Pulse Width : This implies the duration of pulse BELOW the basis of threshold voltage.

This will display the on/off duty cycle time of the component being tested.

![](_page_26_Figure_15.jpeg)

![](_page_26_Figure_16.jpeg)

![](_page_27_Figure_1.jpeg)

Oscilloscope uses 4 channels in total, and there is a 2CH mode and a 4CH mode. The available channels that can be shown on the screen are 1 to 5 channels including AUX channel.

The output data value of cursor a or cursor b, and (MAX)/(AVG)/(MIN)/(FREQUENCY)/(DUTY) value between cursor a and b, can be determined.

![](_page_27_Figure_4.jpeg)

Figure 1. Oscilloscope Function

# Main Screen Menu

# **Icon Description**

lcon	Description
Sensor	Enters SENSOR mode
Theme	Enters THEME mode
2Ch/4Ch	Switch between 2CH mode and 4CH mode.
Aux	Enter to AUX mode
Review	Shows data review.
Reset	Resets measured data to appropriate setting.
Stop 🗢 Start 🗢	Buttons control "STOP" or "RUN" (resume) of current waveform.
Name	Renaming selected channels
	This button activates between two cursors. Every time the button is
Cursor	clicked, cursor A is set to cursor B or, cursor B is set to cursor A.
ViewAll	Shows piled up waveforms.
Trigger	Trigger button which controls "Trig UP" ↔ "Trig DOWN" ↔ "NO TRIG".
SingleShot	Switch button for single shot mode. Single shot button which controls "Trig UP" ↔ "Trig DOWN" ↔ "NO TRIG".

lcon	Description
ZeroSet	Enters zero set at the AUX function. This icon will be enabled when
	using AUX.
Save	Move to data saving. This icon will be shown when current waveforms
	are stopped.
	Used to move graph to the left or to the right. This is only applicable
	when the display is in paused mode and review mode.
🔔 18 ms	Show duration between the two cursors.
4 2.5ms	Buttons change the graph time resolution

#### Sensor

Sensor function shows the waveform in its most optimized form that the user intends to measure. This function prompts a new setting window that the user can select various options, which help properly display the setting for waveform analysis.

It supports Engine and Transmission.

ſ	Sensor	Sensor
	• System Engine • @ 2Ch C 4Ch	• System Engine • C 2Ch @ 4Ch
	Ch A-1 Mass Air Flow Sensor (MAFS)	Ch A-1 Crankshaft Position Sensor (CKPS)
	Ch B-1 Throttle Position Sensor (TPS)	Ch A-2 Camshaft Position Sensor (CMPS)
	• AUX	Ch B-1 CVVT Oil Temperature Sensor (OTS)
		Cn 8-2 Idle Speed Control Actuator (ISCA)
		• AUX
	OK Cancel	OK Cancel

Figure 2. Sensor mode setting

#### Theme

When analyzing more than two waveforms at the same time, this option allows the user to see the most optimized output which the user will be able to analyze more easily.

![](_page_30_Picture_2.jpeg)

Figure 3. Theme mode setting

#### **Explanation of Check box Function**

When using SENSOR and THEME mode, users can select the check box to display the selected information on Component Location, General Description, Waveform, Component Inspection, Component Circuit and Full Circuit

![](_page_30_Picture_6.jpeg)

Figure 4. Choose the Waveform in Sensor or Theme

## 2CH/4CH

Channels available for measuring waveforms are 4channels (CH-A1, CH-A2, CH-B1, CH-B2), plus the SENSOR channel, for total of 5channels.

In 2CH mode, CH-A forms one channel and CH-B forms the other channel for a total of two channels for measuring two different signals. (Differential Mode)

In 4CH mode, each one of CH-A1, CH-A2, CH-B1, CH-B2 probes become available channels. Therefore, a total of 4 channels becomes available (Single Ended Mode), and in this case the ground will be the battery (-) terminal of the vehicle.

![](_page_31_Figure_6.jpeg)

Figure 5. Display 4 Channel Mode

#### \* TIPS

2CH Differential Mode measures differences between (–) probe and (+) probe, and 4CH Single Ended Mode measures voltages using each 4 positive probes. The VMI module becomes the Ground. Refer to [Figure 6].

![](_page_32_Figure_2.jpeg)

Figure 6. 2CH Differential Mode and 4CH Single Ended Mode

![](_page_32_Picture_4.jpeg)

 Probes that are not being occupied must be connected to Battery (-) Terminal in case of using 4CH mode to prevent unnecessary inflows.

# AUX

This channel is for connecting exclusive channel probes for measuring current, engine vacuum or manifold pressure.

#### Review

This function retrieves the saved data for review.

## Reset

This function optimizes the output waveform display in Time (x axis) and Voltage (y axis). After reset, Trigger and Single shot will be cancelled automatically.

#### Start/Stop

Users can stop and analyze waveform data at the users discretion.

#### **User's Manual**

#### Name

Users can customize a name selected waveform data to preferred name subdividing waveforms so that users know exactly what they have recorded.

Channel Name	
Channel A-1 Injector #1	Channel A Ch A
Channel A-2 Ch A2	Channel B Ch B
Channel B-1 Ch B1	Channel AUX Sensor
Channel B-2 Ch B2	OK Cancel

Figure 7. Renaming each channel

#### Cursor

Cursor a and b can be selected by clicking two cursor button. The selected cursor is highlighted with red dotted lines and cursor is moveable. The left out cursor is highlighted dimmer with dotted lines and cursor is fixed.

If the wavelength between the two cursors are less than a one cycle, the frequency and the duty (-) will not be displayed.

![](_page_33_Figure_9.jpeg)

Figure 8. Activates Cursor A

## View All

While retrieving saved data or measuring, this overlaps all waveforms in one screen so that the user can easily examine the waveform data.

Color of each waveform and their names are shown in different colors so that users can distinguish the differences.

![](_page_34_Figure_5.jpeg)

Figure 9. View All Main Screen

#### Trigger

Trigger will show the running waveform signal at the one position it can be done by clicking (by mouse or stylus pen) at a cursor area that the user prefers to analyze.

It is possible to set the trigger function to trigger waveforms that are rising or descending. Click TRIGGER icon to enter trigger mode and confirm the trigger point by placing mouse cursor on waveform that user wants to trigger on.

When you select the trigger function, you will automatically trigger on the positive going waveforms or the (rise). Touching the trigger a second time, you get a trigger point on the descending or fall of the waveform. Touch the trigger point a third time turns the trigger function off.

If users fail to trig, "No Trig" sign will show.

![](_page_35_Figure_7.jpeg)

Figure 10. Trigger Mode

#### Single Shot

Single Shot mode stops and displays a waveform signal automatically if the signal level matches the level that the user selected automatically.

To be able to see periodic waveforms like TPS or MAP, use Single Shot mode. This helps users to see the changing point of waveforms more easily.

After clicking Single Shot Icon, Single Shot Start button will blink if the movable cross cursor is placed on the waveform, then press Single Shot Start button to start data check. [Figure. 11]

![](_page_36_Picture_6.jpeg)

Figure 11. Now Data Checking

# **User's Manual**

When DATA CHECKING is finished, triggered waveform will appear on the oscilloscope screen in freeze mode. [Figure12]

![](_page_37_Figure_3.jpeg)

Figure 12. Single Shot Display

#### Zero Set

This function sets the data back to initial setting while using AUX channel.

Two cursor Duration

Shows the time duration between the two cursors.

**Duration adjustment** 

Showing time selects and sets the time unit per one grid (DIVISION).

#### Configuration Screen Menu

Users can change the setting for each channel (VOLTAGE RANGE, UNI/BI, PEAK/NORMAL, DC/AC, AUTO/MANUAL) by clicking "Configuration" from the main screen of Oscilloscope. Refer to [Figure 13].

![](_page_38_Figure_10.jpeg)

Figure 13. Activating the Configuration window

# **Icon Description**

lcon	Description
▲ 100mV	Adjusting channel voltage for each waveform.
UNI BI	Switches between "Bipolar" mode and "Unipolar" mode.
NORMAL PEAK	Switches between "PEAK" mode and "NORM" mode.
AC DC	Switches between "Alternate current" ↔ "Direct current".
AUTO MANUAL	Adjusts the Voltage (y axis) into optimized setting.
DATA	Shows MAX / MIN / AVG or Hz / Duty(-) / Duty (+) or Cursor a / Cursor
	b / AVG from outputted waveforms.

# Adjusting Channel Voltage

Using the arrow keys, users can change the Y axis (Voltage) and the total input voltage value.

# UNI (Unipolar)

Output only shows (+) area from the base of "0" level and is used to measure waveform of various sensors, actuator and electric sources.

# BI (Bipolar)

Screen output is showing (+), (-) area, on the basis of ground potential or 0V. This mode is used to measure signals off inductive form of CKP, ABS wheel speed sensor, Automatic TR pulse generator A, B and 2<sup>nd</sup> ignition coil.

#### PEAK

It must be in PEAK mode to measure instant signals like surge voltage in devices like Injector, Ignition coil and various solenoid valve devices for better accuracy.

# NORM(Normal)

This mode is to show minimum data depending on the sampling speed (Time/Division). Because this mode does not sample like short period surging, it is convenient for measuring slow signal devices like  $O_2$  sensor.

# AC(Alternate Current)

Because automotive alternators are alternating current and associated systems are direct current, it will show waveforms at the power source regulated down to "0" if direct current frequency is set to alternating current. Therefore it is rarely used except for measuring ripple voltage from the alternator diodes,

#### DC(Direct Current)

Most waveforms are measured in DC.

#### Auto

Displays outputted waveforms on screen at its optimized form.

## DATA

By clicking the "DATA" button, it can display [MAX / MIN / AVG] or [Hz / Duty(-) /Duty (+)] or [Current A / Current B / AVG] of outputted waveforms.

# Full Screen Waveform Show Mode

Displays the individually selected waveform on screen.

🚈 ++ GDS ++ - Microsoft Interne	et Explorer	-     ×
	Preparation Diagnosis Vehicle S/W Management Repair @ LOG OFF @	EXIT
🦸 VCI - USB On 🚪 Internet On	VIN ACCENT(LC) / 2004 / G 1.5 SOHC System ENGINE / UNLEAD EOBD Search Prt So	(R)
Diagnosis 📾	Sensor Theme 2Ch/4Ch Aux Review At 74ms	8
Basic Inspection	Reset Stop Cursor ViewAll Trigger SingleShot ZeroSel 🜗 10ms 🕨	
DTC Analysis	Injector #1 MAX : 43.6 V. MIN : 13.0 V. Avg : -534 mV	8
Data Analysis		
Case Analysis		-
Symptom Analysis		
Flight Record		
Oscilloscope Component Location General Description Component Inspection Component Circuit Full Circuit		
CARB OBD-II	2	
Shop Manual TSB Case Analysis	ETM DTC DTC Current Actuation Flight Record DVOM Oscilloscope Simulation ECU Data Actuation Fight Record DVOM Oscilloscope Simulation ECU Dygrade Searching Feedback Upp	ernet date

Figure 14. Full Screen Display

![](_page_42_Picture_1.jpeg)

Simulation is used for checking solenoid and sensor circuit operation by inputting the appropriate Voltage/Pulse in the ECM fields.

Voltage and Pulse output use CH-B, and Duty Output uses CH-A only.

If the Simulation test fails, the output "0L(over load)" will be indicated.

Voltage, Pulse or Duty will be inputted automatically to circuit by clicking the arrow keys.

![](_page_42_Picture_6.jpeg)

Figure 1. Simulation Test

#### Main Screen Menu

# **Icon Description**

lcon	Description
VOLT(V) Output	Inputting the Voltage that is set by user in the ECM fields.
Pulse Output	Inputting the Pulse that is set by user in the ECM fields.
Duty Output	Ground Control signal is outputted.
Duty Output	Usually used to drive injectors or other solenoid actuations.
	Used for starting or stopping selected Voltage/Pulse/Duty output
	from each modes.

![](_page_43_Picture_5.jpeg)

- Excessive forced simulation test and actuation test can cause malfunctioning of the actuator.
- Forcing an injector over a certain period of time will generate a Wall film effect, which deteriorates operating of spark plug.
- Forcing a solenoid over a certain period of time will deteriorate the function of solenoid.
- Simulation and actuation test has to be completed in a short period to minimize the chances of actuators getting deteriorated.
- When driving a simulation test, if voltage within the circuit does not meet within the range (higher or less), then this feedback values (Voltages or OL) will be shown in RED text and simulation test will be self aborted.

#### Voltage(V) Output

Voltage output uses CH-B only and it checks ECU by sending Voltages instead of a sensor. Using the arrow keys, the input voltage can be adjusted by 1V or 0.1V.

![](_page_44_Picture_4.jpeg)

Figure 2. Voltage Output Main Screen

![](_page_44_Picture_6.jpeg)

- At a certain voltage output using the Voltage output mode, if input values are not changing, the values at sensor could be higher than selected input voltage or ECM has PULL-UP voltage value. Therefore it is not a system error.
- Do not apply probe (+) and probe (-) in reverse.
- During the Voltage or Pulse Output function, sensor connector has to be disconnected. If not the input signal (Voltage or Pulse Output) could be mixed with sensor signal.

# **Icon Description**

lcon	Description
	When setting output VOLTAGE, raise the value by 1V
	When setting output VOLTAGE, low the value by 1V
	When setting output VOLTAGE, raise the value by 0.1V
	When setting output VOLTAGE, low the value by 0.1V

During the Voltage Output function, VMI is using the circuit as below. Refer to [Figure 3].

When user starts to output the specific voltage(setting by user) with CH-B1, this output signal will be sent from CPU to D/A Converter as an analog signal. The D/A Converter will convert this analog signal to digital signal and send it to CH-B1 through the Output Circuit. In this moment, CH-B2 has to be connected to battery (-) terminal.

Voltage Output function has voltage feedback circuit also, and it uses checking voltage from actual sensor circuit that the user wants to test at the vehicle. Then if this feedback signal(Voltage) does not meet within specific value, then the feedback values(Voltage) will be shown in RED text at the setting window, and simulation test will be self aborted.

![](_page_45_Figure_7.jpeg)

Figure 3. Voltage Output Block Diagram

# **User's Manual**

Voltage Output uses CH-B only; the connecting methods are as below.

Disconnect sensor connector.

CH-B1 (+) : Connect to Sensor Control Circuit

CH-B2 (-) : Connect to Sensor Ground Circuit

Refer to [Figure 4].

![](_page_46_Figure_7.jpeg)

Figure 4. Probe Connecting Method for Simulation Test

#### Pulse Output

A duty cycle signal (in Hertz) made by Pulse output function is sent to an ECU instead of the signal from a specific sensor.

Using the arrow keys, the input pulse can be adjusted by 1Hz or 10Hz.

![](_page_47_Picture_5.jpeg)

Figure 5. Pulse Output Main Screen

# **Icon Description**

lcon	Description
	When setting output FREQUENCY, raise the value by 10Hz.
	When setting output FREQUENCY, low the value by 10Hz.
	When setting output FREQUENCY, raise the value by 1Hz.
	When setting output FREQUENCY, low the value by 1Hz.

During the Pulse Output function, VMI is using the circuit as below. Refer to [Figure 6].

When user starts to output the specific pulse signal(setting by user) with CH-B1, this output signal will be sent from CPU to D/A Converter as an analog signal. The D/A Converter will convert this analog signal to digital signal and send it to CH-B1 through the Output Circuit. In this moment, CH-B2 has to be connected to battery (-) terminal.

Pulse Output function has voltage feedback circuit also, and it uses checking voltage from actual sensor circuit that the user wants to test at the vehicle. Then if this feedback signal(Voltage) does not meet within specific value, then the feedback value(OL) will be shown in RED text at the setting window, and simulation test will be self aborted.

![](_page_48_Figure_7.jpeg)

Figure 6. Pulse Output Main Screen

# **User's Manual**

Pulse Output uses CH-B only; the connecting methods are as below.

Disconnect sensor connector.

CH-B1 (+) : Connect to Sensor Control Circuit

CH-B2 (-) : Connect to Battery (-) Terminal

Refer to [Figure 7].

![](_page_49_Figure_7.jpeg)

Figure 7. Probe Connecting Method for Simulation Test

## **Duty Output**

Duty Output function forces the actuator to operate with the user-preferred setting Hertz and Duty(-) to determine whether actuation is working properly or not.

Probes should be connected as shown in [Figure 10] and select appropriate signals (Duty & Hz), then press Start button to start the test.

![](_page_50_Figure_5.jpeg)

Figure 8. Duty Output Main Screen

🛃 💀 GDS 💀 - Microsoft Intern	et Explorer	_0×
gd?	Preparation Diagnosis Vehicle S/W Management Repair	LOG OFF BEXIT
🕴 VCI (USB On 🍍 VMI): On 🚪	Internet On VIN ACCENT(LC) / 2004 / 0 1.5 SOHC System ENGINE / UNLEAD EOBD	Search Prt Sc 🚱
Diagnosis 🔿	Simulation Test (Channel A Only 000)	8
Basic Inspection	VOLT(V) Output Pulse Output Duty Output Hz Duty(%)	
DTC Analysis		
Data Analysis Component Location General Description Fault Detecting Condition OperAlitation Component Circuit Full Circuit	Duty Output 24 % 10 Hz 1 Hz 10 Hz 1 Hz We channel A probe Only I Use this function for earth controllable actuator Only I	UII STOP
Case Analysis Symptom Analysis Flight Record Oscilloscope CARB OBD-II	VMI PC CFA Rose Battery -+	
Shop Manual TSB Case Analysis	ETM DTC Current Actuation Flight DVOM Oxideoxye Struktion UCC Starting Structure Structure Structure Starting Upgrade Starting	Knowledge Feedback

Figure 9. Hertz Output Main Screen

# **Icon Description**

lcon	Description
	Button for adjusting output frequency.
14	After pressing this button, control with UP / DOWN button.
Duty(%)	Button for adjusting output duty.
	After pressing this button, control with UP / DOWN button.
	When setting output FREQUENCY/DUTY, raise the value by 10Hz/%.
$\overline{}$	When setting output FREQUENCY/DUTY, low the value by 10Hz/%.
	When setting output FREQUENCY/DUTY, raise the value by 1Hz/%.
	When setting output FREQUENCY/DUTY, low the value by 1Hz/%.

Actuation Test uses CH-A channel, the connecting methods are as below.

CH-A1 (+): Connect to Actuator Control Circuit

CH-A2 (-) : Connect to battery (-) terminal

Refer to [Figure 10].

![](_page_51_Figure_8.jpeg)

Figure 10. Probe Connecting Method for Actuation Test

Actuation test is applied input signal to control circuits like [Figure 11]. Instead of ECU sending input signal, VMI can send duty signal to test whether actuator is working properly or not.

If sensor circuit, which is user, wants to test, has more than 2A present, the Duty Output will be self aborted to prevent circuit damage refer to [Figure 12].

![](_page_52_Figure_4.jpeg)

Figure 11. General Idea of Duty Output

![](_page_52_Figure_6.jpeg)

Figure 12. Allowed Current Value Has Exceeded

![](_page_52_Picture_8.jpeg)

- To prevent circuit damage, actuator function has certain limits on voltages and current.
- Scope cable must be firmly connected before starting actuator test.
- Do not apply probe (+) and probe (-) in reverse.